
JACK-SCREW TYPE MOUNTS: 6CP & 8CP




- Elastomer vibration & shock mount
 protects environment against transmitted vibration & shock
 protects sensitive equipment from incoming vibration & shock
- Jack Bolt leveling screw
- Proper machine support
- Proprietary elastomer cushions
 oil and chemical resistant
 - multiple hardness & thickness for better isolation effectiveness
- •neoprene, nitrile standard compounds
- Meets OSHA anchoring requirements

CUSTOM DESIGNS & SIZES ARE AVAILABLE







Installation Instructions

- 1. Floor under isolator should be flat, level, clean and dry, with no bumps, holes, or cracks,
- 2. Screw the "CP" screw into the machine base as far as possible,
- 3. Carefully lower the machine so the "pin" end of the "CP" screw fits into the isolator mounting hole,
- 4. Level the machine by using a wrench to adjust the "CP" screws to raise the low side and end of the machine.

CAUTION!

Do not unscrew the "CP" screws out of the machine base by over-adjusting them.

NOTE: Isolator data subject to change without notice.

05/02/2019



2243 Braga. Drive, Broadview, IL 60155 tel.: 800.842.7668 • vibro@vibrodynamics.com www.vibrodynamics.com